



3M™ 6000 Series Half Mask

Cleaning and Inspection



Before Use

- Inspect respirator for incorrectly fitted and/or damaged parts.
- Inspect the exhalation valve and seat.

After Use

- Cleaning is recommended after each use
- Remove the gas/vapour and/or particulate filters
- Clean with 3M 105 wipe or by immersing in warm cleaning solution, water temperature not to exceed 50°C, and scrub with a soft brush until clean
- Rinse in fresh warm water
- Air dry in a non-contaminated atmosphere

Monthly

- Carry out all the 'Before Use' inspections
- Check:
 - Face Seal
 - Straps and Head Harness
 - Valves
- Create record of this monthly check

Ordering Consumables and Accessories

To request a quote or place an order for these items, please contact your 3M Approved Distributor.

Further Information and Advice

If you require additional guidance on the Care and Maintenance of your 3M Reusable Respirators, please contact the Helpline.

3M Health and Safety Helpline

0870 60 800 60 (UK)
1 800 320 500 (Ireland)

IF ANY PARTS ARE DAMAGED DO NOT USE